



Einhell

EXPERT

POWER X-CHANGE

Cordl. Multi Purpose Spreader

GE-SR 18/22 Li-Solo

Item No.: 3415430

Ident No.: 21013

Bar Code: 4006825673142

The Einhell cordless spreader GE-SR 18/22 Li-Solo is suitable for evenly distributing dry spreading material such as seeds, seeds, fertiliser or road salt all year round. As a member of the Power X-Change family, the spreader can be combined with all Power X-Change batteries and chargers. The amount of spread can be adjusted in 6 stages and the spreading speed can be adjusted in 6 stages thanks to the electronic speed control. The spreading width can also be individually adjusted from 1,5 to 6 metres. The container holds up to 22 litres of spreading material. Thanks to the large wheels and the ergonomic push bar, the cordless spreader can be optimally guided. Supplied without battery or charger.

Features & Benefits

- Part of the Power X-Change family, 1 x 18 V battery required
- 6-stage, electronically adjustable spreading speed
- 6-stage adjustable spreading quantity
- Large 22-litre volume container
- Individually adjustable spreading width up to 6 metres
- Possible year-round use: Fertiliser, lawn seeds, road salt
- Large push bar for precise, comfortable manoeuvring
- Optimal handling thanks to large wheels
- Ergonomic and safe handling thanks to Softgrip
- Comes without battery or charger (sold separately)



Technical Data

- Voltage: 18 V
- Min. spreading width: 1.5 m
- Max. spreading width: 6 m
- Spreading rate adjustment (steps): 6
- No-load speed adjustment (steps): 6 settings



Logistic Data

- Product weight (kg): 6.43
- Gross weight (kg): 9.03
- Dimensions single packaging: 470 x 440 x 520 mm
- Pieces per export carton: 1 Pieces
- Gross weight of export carton: 9.03 kg



Available as special accessories



4-6 Ah Multi-Ah Power X-Change Plus Battery
Item No.: 4511502
Bar Code: 4006825644210



4,0 Ah Power X-Change Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



Power X-Fastcharger 4A Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



PXC Battery Mounting Gadget PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



18V 5-8Ah Multi-Ah PXC Plus Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



5,2 Ah Power X-Change Plus Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



2,0 Ah Power X-Change Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 2,5Ah PXC Starter Kit PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x2 Power X-Quattrocharger 4A Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



2x 5,2Ah & Twincharger Kit PXC-Starter-Kit
Item No.: 4512108
Bar Code: 4006825652376
Einhell Accessory



18V 3,0 Ah Power-X-Change 1 Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1 PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



5,2Ah & 4A Fastcharger PXC-Starter-Kit
Item No.: 4512114
Bar Code: 4006825656787
Einhell Accessory



3,0 Ah Power X-Change Plus Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



18V 4-6Ah & 6A Boostcharger PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah Power-X-Change Plus Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



18V Battery Charger 3,0A - PXC Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory