



Einhell

EXPERT



Cordless Lawn Trimmer
GE-CT 18/28 Li Kit (1x2,0 Ah)

Item No.: 3411244

Ident No.: 21034

Bar Code: 4006825664492

The Einhell cordless lawn trimmer GE-CT 18/28 Li Kit (1x2.0 Ah) is a lightweight and powerful Power X-Change system device and is easy to use thanks to the infinitely adjustable second handle, softgrip and the infinitely telescopic guide rail for individual adaptation to each user's height. The motor head, which can be tilted into 3 different positions, can be rotated through 180°, so that even vertical surfaces and lawn edges can be processed flexibly. The flowerguard protects plants and trees from damage. A thread spool (5 m) with fully automatic thread tracking is included in delivery. Delivery includes a battery and charger. 1x 18 volt battery is required for operation of the cordless lawn trimmer.

Features & Benefits

- Member of the Power X-Change family; 1x18 V batteries required
- Infinitely adjustable second handle
- Infinitely telescopic guide bar: Adapted to user height
- 180° rotatable motor head: For vertical surfaces/lawn edges
- 3 motor head tilt positions allow flexible working
- Flowerguard – protects plants and trees from damage
- Incl. thread spool (5 m) with fully automatic thread tracking
- Softgrip – perfect comfort
- Delivery includes a battery and charger

Technical Data

- Accumulator	18 V 2000 mAh Li-Ion
- Max. running time	40 min
- Charging time	40min
- Number of accumulators	1 Pieces
- Revolutions of thread	8000 rpm
- Cutting width of thread	280 mm
- Thread length	500 cm
- Thread diameter	1.6 mm
- Readjustment of thread	Full automatic
- Cutting feature	Single line

Logistic Data

- Product weight	2.7 kg
- Gross weight single packaging	4.15 kg
- Dimensions single packaging	242 x 128 x 1045 mm
- Pieces per export carton	4 Pieces
- Gross weight export carton	17.6 kg
- Dimensions export carton	1060 x 500 x 270 mm






TILT- AND TURNABLE



FLOWERGUARD



TELESCOPIC



Available as special accessories



Spare line spool GE-CT 18/28
Lawn Trimmer Accessory
Item No.: 3405116
Bar Code: 4006825655216
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



PXC 18V 4,0Ah
Battery
Item No.: 4514079
Bar Code: 4006825674316
Einhell Accessory (Discounter)



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 4,0Ah PXC Starter Kit A1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 2,0Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512040
Bar Code: 4006825613681
Einhell Accessory



5,2 Ah PXC Starter-Kit
PXC-Starter-Kit
Item No.: 4512147
Bar Code: 4006825675153
Einhell Accessory



4Ah PLUS PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512159
Bar Code: 4006825680331
Einhell Accessory