



Einhell

EXPERT



Cordless Lawn Trimmer
GE-CT 18 Li (1x 2,5Ah)

Item No.: 3411219

Ident No.: 21024

Bar Code: 4006825680812

The GE-CT 18 Li (1x 2,5 Ah) grass trimmer is a powerful device which ensures a well-maintained lawn wherever the lawn mower cannot reach. As a member of the Einhell Power X-Change family, the trimmer can be utilised wirelessly and flexibly for extended, off-grid independent work. The cordless grass trimmer is delivered in a kit with a 2.5 Ah Power X-Change battery and a charging device. Due to the soft grip, infinitely adjustable second handle with integrated blade compartment and the motor head, which can be rotated +/- 90° and tilted 5 times, even difficult areas such as vertical surfaces and lawn edges can be worked on effortlessly. 20 plastic knives are supplied.

Features & Benefits

- Member of the Power X-Change family, 1x 18 V battery required
- Infinitely adjustable second handle
- Infinitely telescopic guide bar
- Motor head +/- 90° rotatable: For vertical surfaces/lawn edges
- 5-position tiltable motor head for flexible operation
- Flowerguard protects plants and trees from damage
- Soft grip for comfortable handling
- Integrated storage compartment for 20 blades
- Incl. 20 plastic blades
- Comes with 1x 2.5 Ah battery and charger

Technical Data

- | | |
|--------------------------|--------------------------|
| - Accumulator | 18 V 2500 mAh Li-Ion |
| - Number of accumulators | 1 Pieces |
| - Revolutions of knife | 8500 rpm |
| - Cutting width of knife | 24 cm |
| - Number of knives | 20 Pieces |

Logistic Data

- | | |
|---------------------------------|---------------------|
| - Product weight | 2.25 kg |
| - Gross weight single packaging | 3.84 kg |
| - Dimensions single packaging | 205 x 125 x 988 mm |
| - Pieces per export carton | 4 Pieces |
| - Gross weight export carton | 15.36 kg |
| - Dimensions export carton | 1000 x 415 x 260 mm |



TILT- AND TURNABLE





TELESCOPIC



FLOWERGUARD



INCL.



Available as special accessories



Spare Blade-set PXC Trimmer
Lawn Trimmer Accessory
Item No.: 3405730
Bar Code: 4006825560404
Einhell Grey



Spare Blade-box PXC trimmer
Lawn Trimmer Accessory
Item No.: 3405736
Bar Code: 4006825646283
Einhell Accessory



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory

Battery-Running-Times



trimming¹
(min.)

One Battery for All

1.5 Ah	40
2.0 Ah	55
2.5 Ah	65
3.0 Ah	80
4.0 Ah	125
5.2 Ah	160
6.0 Ah	180
8.0 Ah	250

Test setup:

1) lawn