



Einhell

EXPERT



Cordless Energy Station

TE-ES 18/150/1 Li-C-Solo

Item No.: 1091310

Ident No.: 21014

Bar Code: 4006825683172

The Einhell TE-ES 18/150/1 Li-C-Solo cordless power station is the ideal solution for mobile power supply – at home, on the go, or while camping. Compatible with the Power X-Change battery system, it features a 230V socket for devices up to 150 watts, a 12V port for up to 120 watts, and USB-A (10W) and USB-C PD (60W) ports for fast charging. The Power X-Change battery can be charged via USB-C input with a power adapter (not included). Equipped with a carrying handle, soft-grip surface, LED light, and charge status display, it is practical and robust. Ports are protected by dustproof covers. Battery and charger are sold separately.

Features & Benefits



- Member of the Power X-Change family, requires one 18V battery
- Compact inverter for charging various devices
- 230V socket for powering and charging devices such as laptops
- USB-C PD and USB-A ports for charging smaller devices
- Battery can be charged using a power adapter
- Ports are protected against dust and dirt
- Soft-grip surface ensures stability and secure handling
- Ergonomic handle for easy transport
- LED display provides detailed battery status information
- Sturdy hook allows for quick and easy storage
- Incl. 12V port for operating devices such as cool boxes
- Incl. dimmable LED light
- Battery and charger are not included

Technical Data

- | | |
|------------------------|----------|
| - No. of battery slots | 1 Pieces |
|------------------------|----------|

Logistic Data

- | | |
|--------------------------------------|----------------------|
| - Product weight (kg) | 0.66 |
| - Gross weight (kg) | 0.88 |
| - Dimensions single packaging | 142 x 97 x 191 mm |
| - Pieces per export carton | 12 Pieces |
| - Gross weight of export carton | 11.02 kg |
| - Dimensions export carton | 445 x 335 x 225 mm |
| - Container quantity (20"/40"/40"HC) | 9660 17676 23244 |



Available as special accessories



PXC Battery Mounting Gadget
PXC-Battery Accessory
Item No.: 4514155
Bar Code: 4006825658774
Einhell Accessory



5,2 Ah Power X-Change Plus
Battery
Item No.: 4511437
Bar Code: 4006825616606
Einhell Accessory



PXC+ 18V 5-8Ah MULTI
Battery
Item No.: 4511600
Bar Code: 4006825665055
Einhell Accessory



PXC+ 18V 4,0Ah SEALED
Battery
Item No.: 4511627
Bar Code: 4006825673227
Einhell Accessory



PXC+ 18V 4,0Ah
Battery
Item No.: 4511553
Bar Code: 4006825660869
Einhell Accessory



PXC+ 18V 3,0Ah SEALED
Battery
Item No.: 4511618
Bar Code: 4006825672794
Einhell Accessory



PXC 18V 3,0Ah
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



3,0 Ah Power X-Change Plus
Battery
Item No.: 4511501
Bar Code: 4006825644197
Einhell Accessory



2,0 Ah Power X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



4,0 Ah Power X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



4-6 Ah Multi-Ah Power X-Change
Plus
Battery
Item No.: 4511502
Bar Code: 4006825644210



2x 18V 5,2Ah PXC-Twinpack
Battery
Item No.: 4511526
Bar Code: 4006825656695
Einhell Accessory



18V 4Ah PXC Plus Twinpack
Battery
Item No.: 4511629
Bar Code: 4006825673685
Einhell Accessory



18V 3Ah PXC Plus Twinpack
Battery
Item No.: 4511631
Bar Code: 4006825673692
Einhell Accessory



2x18V 4,0Ah PXC-Twinpack CB
B1
Battery
Item No.: 4511489
Bar Code: 4006825638578



2x2 Power X-Quattrocharger 4A
Charger
Item No.: 4512102
Bar Code: 4006825649536
Einhell Accessory



Power X-Fastcharger 4A
Charger
Item No.: 4512103
Bar Code: 4006825650228
Einhell Accessory



Power X-Twincharger 3A
Charger
Item No.: 4512069
Bar Code: 4006825629729
Einhell Accessory



Power X-Car Charger 3A
Charger
Item No.: 4512113
Bar Code: 4006825655377
Einhell Accessory



Power X-Boostcharger 8A
Charger
Item No.: 4512155
Bar Code: 4006825670554
Einhell Accessory



18V Battery Charger 3,0A - PXC
Charger
Item No.: 4514095
Bar Code: 4006825655292
Einhell Accessory



18V 2,5Ah PXC Starter Kit
PXC-Starter-Kit
Item No.: 4512097
Bar Code: 4006825646962
Einhell Accessory



2x 4,0Ah & Twincharger Kit 1
PXC-Starter-Kit
Item No.: 4512112
Bar Code: 4006825655766
Einhell Accessory



18V 4-6Ah & 6A Boostcharger
PXC-Starter-Kit
Item No.: 4512143
Bar Code: 4006825667653
Einhell Accessory



18V 4,0Ah PXC Starter Kit B1
PXC-Starter-Kit
Item No.: 4512042
Bar Code: 4006825613704
Einhell Accessory



E-Case L with wheels
System Carrying Case
Item No.: 4540014
Bar Code: 4006825660562
Einhell Accessory



E-Case Tasche
System Carrying Case
Item No.: 4540036
Bar Code: 4006825677966
Einhell Accessory



E-Case S-F
System Carrying Case
Item No.: 4540011
Bar Code: 4006825653991
Einhell Accessory



E-Case M
System Carrying Case
Item No.: 4540021
Bar Code: 4006825667721
Einhell Accessory



E-Case Werkzeugkiste
System Carrying Case
Item No.: 4540037
Bar Code: 4006825677973
Einhell Accessory